



# senseBox

A do-it-yourself toolkit for stationary and mobile sensor stations.


Digital education in STEM subjects.



# « go social

## Content

senseBox:edu	04
Graphical programming	06
Open Educational Resources	08
senseBox:home	10
openSenseMap	12
About us	14



# senseBox:edu

## » Programming and experimenting with environmental sensors

The senseBox:edu is our electronic kit for schools and young researchers, where the focus is on experimenting and programming using sensors. In addition to a programmable open-source microcontroller unit (MCU) based on the Arduino platform, sensors, components for transferring data to the Internet and other accessories are supplied.

With the senseBox:edu you can learn the basics of computer science with real problems from the whole STEM area. You will learn how to program different measuring instruments with little effort. This makes senseBox an optimal school material and is already used in many schools and universities.

Sensors for measuring various environmental phenomena, such as temperature, humidity, air pressure, illuminance, UV radiation, volume, distance, inclination and orientation allow creative work on a wide range of topics. Using the WiFi module, measured values can be transferred to our web platform for open sensor data, the openSenseMap, using the WiFi module. With openSenseMap you can publish all measurements taken with your senseBox and access over a million data sets from thousands of senseBox stations without charge (see page 12). The senseBox:edu can be used in secondary schools for pupils aged 10 and above.



By integrating it into different teaching units, for example:

- » Weather, climate and climate change
- » Light and environmental pollution
- » Internet of Things
- » Getting Started with Programming
- » Measurement and evaluation

senseBox: Sketch\_Name

Open Blocks Save Blocks Save Sketch Delete All

senseBox sensors

senseBox output

- Display
- Web
- SD
- Logic
- Loops
- Math
- Text
- Variables
- Input/Output
- Time
- Advanced

Arduino run first:

- Initialise Display

Arduino loop forever:

- Print on Display
- Font color White
- set font size to 1
- x 0
- y 0
- value

Temperature/Humidity Sensor (HDC1080)

value: Temperature in °C

Arduino Source Code

```
#include <SPI.h>
#include <Wire.h>
#include <Adafruit_GFX.h>
#include <Adafruit_SSD1306.h>
#include <senseBoxIO.h>
#include "SenseBoxMCU.h"

#define OLED_RESET 4
Adafruit_SSD1306 display(OLED_RESET);

HDC1080 hdc;

void setup() {
    senseBoxIO.powerI2C(true);
    delay(2000);
    display.begin(SSD1306_SWITCHCAPVCC, 0x3D);
    display.display();
    delay(100);
    display.clearDisplay();
    hdc.begin();
}
```

Blocks XML


Arduino IDE output


# Graphical programming

## » Blockly for senseBox

With a graphical programming interface we have developed a simple method to program the senseBox. For this purpose, blocks for the individual components and functions of senseBox:edu were integrated into the Blockly system. The individual sensors can be easily read without working with source code and the values can be displayed on the OLED Display. The Arduino source code is displayed in parallel. Blockly for senseBox is available on the web and as download for Mac and Windows.

For advanced applications the senseBox:edu can also be programmed directly in the Arduino IDE (programming environment of Arduino) in the traditional way.






<https://sensebox.de/en/material>

# Open Educational Ressources

## » Instructions from and for the community

The idea of senseBox:edu was developed as a product within workshops for pupils, students and teachers at the student laboratory at the GI@-School Lab at the Institute for Geoinformatics in Münster. Basis course concepts and projects from these workshops were documented and adapted aiming the usage in school lessons. You can find a lot of manuals, videos and documentation material about the senseBox under open licenses.

Together with scientists, schools and the Open-Hardware community, we are constantly improving and expanding the documentation.






senseBox:home

# senseBox:home

## » Open source environmental measurement technology as a kit for home use

The idea for senseBox:home was developed in the context of Citizen Science research at the Institute of Geoinformatics at the University of Münster. The aim of this research is to establish a large and close-meshed sensor network with the help of public participation in order to facilitate access to environmental data for both scientists and the public. In the meantime, the senseBox project together with its data platform openSenseMap (p.12) has grown to one of the most successful and multiple award-winning open-source initiatives in the research field of Citizen Sciences. Due to the open approach and the do-it-yourself character, the project offers the possibility to deal with

innovative sensor technologies, programming and the Internet of Things without any previous knowledge. Which phenomena are measured and how data is transferred can be adapted modularly to many applications. The range is constantly being expanded with new sensors and components. Each new measuring station helps to describe environmental phenomena in a local context and to develop new questions or to improve climate models. Join-in the research and set up your own senseBox:home environmental measuring station.



<https://opensensemap.org/>

# openSenseMap

» Publish, share, download and analyze sensor data

The openSenseMap is an open data platform for any kind of location-related measurement data. The result is an open and comprehensive measurement data network, which is freely available for everyone. The senseBox:edu can be registered in a few steps. Assuming Internet access, the measurements carried out are then automatically uploaded and displayed. The openSenseMap offers various online analysis tools and allows users to download or visualize the data. On the openSenseMap you cannot only find data that were recorded with senseBoxes, but also data from other measuring

stations. These features make the openSenseMap the first contact point for open sensor data.



The senseBox team at the annual hackathon for children and teenagers from the Münster region.

# About us

## » Motivation and outlook

The senseBox was developed within a BMBF research project at the Institute of Geoinformatics at the University of Münster. The resulting project and research work have won several awards in the university competition of the Federal Ministry of Education and Research (BMBF) (2013, 2014 and 2016). In addition, the senseBox:edu received the special prize for Digital Learning and Teaching at the CeBIT Innovation Award 2017.

In 2018 Reedu GmbH & Co KG was founded as a spin-off from the research project. Reedu ensures that further development and distribution of the

senseBox scale with the increasing demand for citizen science tools in education and society. Reedu is supported by the Federal Ministry of Economics and Energy and the European Social Fund as part of the EXIST programme. The spin-off could win already awards in its first year of operation, such as the first place in the GERMAN EDU Start-up Pitch at Didacta 2018.

The awards and especially the positive feedback from the public encourage us to develop the project together with the community into a pioneering project for digital education and citizen science.

The senseBox can easily be ordered online at <https://sensebox.kaufen>.

# Sponsors & Contact



WESTFÄLISCHE  
WILHELMUS-UNIVERSITÄT  
MÜNSTER



ifgi  
Institute for Geoinformatics  
University of Münster



**Make Light**  
Photonik selber machen



BMBF INITIATIVE VOM  
Bundesministerium  
für Bildung  
und Forschung

re:edu  
reengineering education

senseBox



Bundesministerium  
für Wirtschaft  
und Energie

**exist**  
Existenzgründungen  
aus der Wissenschaft

**ESF**  
Europäischer Sozialfonds  
für Deutschland



Zusammen. ★  
Zukunft. ★  
Gestalten. ★

re:edu GmbH & Co. KG  
Institute for Geoinformatics

University of  
Münster

Heisenbergstraße 2  
48149 Münster

+49 (0)251 83 33 166  
[info@sensebox.de](mailto:info@sensebox.de)